

Extra Heavy Duty Embossing Press

Installation and maintenance instructions



The Extra heavy Duty Embossing Press must be bolted down to a sturdy bench at all times, to stop it travelling off the bench or toppling over.

Every few months or before a period of heavy use, apply a small amount of “high temperature bearing grease” half way up the main screw. This type of grease will not run excessively in hot weather. The grease will find its way along the main screw during use.

Spray or put a few drops of light machine oil in the two holes at each side at the top of the press, which are the tops of the return spring pockets. Suitable light machine oils are 3-in-One Oil or WD40. This is so that the return springs operate smoothly.

At all times check for pools of oil or grease sitting above the top die, or anywhere which can come in contact with your papers. If there are, wipe them away with a paper tissue or cloth.

www.rubberstamp.uk.com